# HOUSE OF \_\_\_\_\_ DURATECH innovative pool products \_\_\_\_





# PL-REM-60



12-09-22

# LINK Driver

# **Table of contents**

Page 3
Page 4
Page 5
Page 6
Page 7
Page 7
Page 8

# DURALINK

**Technical specifications** 

## **Electrical specifications**

Nominal Input voltage Output voltage on Lamp Output Max output current on Lamp Output Transformer VA rating Frequency band transmitter IEC Protection Class 230 VAC 50 Hz 12 VAC 5A 60VA 868 MHz Class II


#### General specifications Controller

Ambient air temperature Humidity

Dimensions Weight Ingress Protection Rate 0°C ... +40°C 10% ... 90% RH non condensing 150x157x51 mm 1,3 kg IP54

## **Box contents**

- 1. PL-REM-60 controller
- 2. Handheld transmitter
- 3. Spare battery
- 4. Screws (4x) & wall plugs (4x)
- 5. Owner's Manual














# **Installation instructions**

- Connect a 230VAC power source to the "220-240VAC INPUT" terminal.
- Connect the swimming pool lights to the "Lamp 12VAC output" terminal

Make sure the total load of pool lights does not exceed 60Watt



# Pairing handheld transmitter & controller

The handheld transmitter is already paired in the factory and ready to use. The PL-REM-60 can pair with up to 6 handheld transmitters. In case a problem arises, the pairing process can be done manually:

#### Manual Pairing process:

Make sure the PL-REM-60 is connected to a power source.

1. Press the pairing button on the small circuit board, inside the controller for at least 5 seconds.


--> The LED will start to blink fast

- 2. Within 25 seconds, press any button on the handheld transmitter.
  - --> If the transmitter is paired correctly, the LED will flash slowly for 5 times
  - --> If the PL-REM-60 pairing memory is full, the LED will flash 15 times. This means 6 handheld devices have already been paired.


To unpair all handheld transmitters with the controller: Push the pairing button for at least 5 seconds, then do nothing for at least 25 seconds.

--> The pair memory will be erased - the green LED will flash 5x on/off.

⚠️ If no transmitters are paired, the PL-REM-200 will accept messages from any transmitter!



# Handheld transmitter functions



# **Replacing transmitter battery**

- Remove the philips head screw and open the transmitter
- Replace the battery, respecting the polarity

Battery type: A23 12V





# Troubleshooting

PROBLEM	SOLUTION
The controller doesn't react to transmitter commands	<ul> <li>Check the battery of the handheld transmitter</li> <li>The transmitter is not paired correctly with the controller. Repeat the pairing process</li> <li>Reduce the distance between handheld transmitter and PL-REM-60 and/or eliminate obstacles</li> </ul>
The pool lights don't work	<ul><li>Check the red status LED</li><li>Check if there is 12VAC output</li></ul>

at the terminals of the controller

#### **Declaraction of Conformity**

Declarations of conformity covering this product are available for download from the House of Duratech website: www.duratech.be

## Notes

#### - HOUSE OF -RAT innovative pool products

#### **DURAVISION**

#### Pool Light products

- VISION Moonlight
- VISION Spectra
- VISION Adagio Pro
- VISION Pro
- VISION Wall Conduits
- VISION Faces Plates
- VISION Specials

#### DURAHEAT

- Heat Pump products
- HEAT Hot Splash
- HEAT Sun Spring
- -HEAT Dura V
- -HEAT Dura Vi
- -HEAT Dura +i
- -HEAT Dura Pro
- HEAT Accessories

#### **DURA**FLOW

**Pool Flow** products

```
FLOW Inverter
```

#### **DURACOVER**

- COVER Tube
- COVER Motor
- COVER Wall Duct
- COVER Cable Duct
- COVER Hanging System

#### DURALINK

Cover System products Control products

#### - LINK Driver

- LINK Touch
- LINK Controller
- LINK Cover
- LINK Master
- LINK Accessoires



# **Contact details**

### **Propulsion Systems bv**

Dooren 72 1785 Merchtem, Belgium

Tel +32 2 461 02 53

www.duratech.be info@propulsionsystems.be



# DURALINK



We reserve the rights to change all or part of the contents of this document without prior notice